

Flame Aroma Diffuser Instructions

Basic parameters

Product model: D631

Rated power: $\leq 6.5W$

Rated input: DC5.0V 2A

Product weight: 407g

Product size: 132x132x149mm

Implementation standard: GB4706.1-2005

GB 4706.48-2009

Origin: Shenzhen, China

Instructions

Short press the switch button to turn on the aromatherapy atomization and turn on all the lights at the same time; Then short press to turn intermittent spray; Short press again Close all.

Short press the timing button to start the timing function; Short press again to convert the timer.

Short press the light button to turn on the flame light; Then short press the colorful gradient; Then short press to fix the color of the light; Then short press to turn the dazzling lamp color; Press again to turn off the light. Press and hold to switch between the up and down lights.

Protection function: Built-in water shortage protection chip, automatic stop working after no water is detected.

Precautions

The maximum water volume of the water tank is 200 ml. The water injection volume cannot exceed the maximum water level indicator line, otherwise it will affect the atomization effect. Please use DC5V $\overline{\text{---}}$ 2A input power supply, otherwise it will affect the atomization effect or cause damage to the host. Please add pure water to the atomizer to avoid damage to the atomizer function due to impurities in the water, so as to achieve the best maintenance effect. The sound emitted from the inside of the water tank during operation is the sound of the atomizer working; it is a normal phenomenon. Unplug when filling and cleaning.