


## INSTRUCTIONS

### Double folding scissor foot keyboard



| FN+<br>Key icons | IOS<br>system function   | Android<br>system function | Windows<br>system function |
|------------------|--------------------------|----------------------------|----------------------------|
|                  | Main page                | Main page                  | IE homepage                |
|                  | Search                   | Search                     | Search                     |
|                  | Select all               | Select all                 | Select all                 |
|                  | Copy                     | Copy                       | Copy                       |
|                  | Paste                    | Paste                      | Paste                      |
|                  | Cut                      | Cut                        | Cut                        |
|                  | Previous song            | Previous song              | Previous song              |
|                  | Play/Pause               | Play/Pause                 | Play/Pause                 |
|                  | Next song                | Next song                  | Next song                  |
|                  | Vol                      | Vol                        | Vol                        |
|                  | Volume increase          | Volume increase            | Volume increase            |
|                  | Lock screen              | Lock screen                | Lock screen                |
|                  | First row                | First row                  | First row                  |
|                  | Page header              | Page header                | Page header                |
|                  | End of page              | End of page                | End of page                |
|                  | End of line              | End of line                | End of line                |
|                  | Function combination key | Function combination key   | Function combination key   |

#### Instructions for Use [English]

##### ■Equipment system matching instructions

After a successful BT keyboard connection, it must be matched with your tablet system.

1. Press and hold the Fn+ Android/Windows/IOS combination key to match the Android/Windows/IOS system. At this time, the Caps/BT LED will flash twice and then turn off.
2. Note: If system matching is not performed, there may be discrepancies between some input characters and key content.

##### ■Keyboard pairing and connections steps

1. Turn the power switch of the keyboard to ON, and the Power LED will light up for 1-2 seconds before automatically turning off.
2. Press the Connect button, and the BT LED will flash, indicating that the keyboard is in a paired connection state.

Note: If pairing is not performed for more than 1 minute, the keyboard will automatically enter standby mode. At this time, you need to press the Connect button again to start pairing.

3. Open the settings of the tablet - BT, find the BT name in the search and click connect.

Note: Password free connection, BT LED will turn of after successful connection.

##### ■Special reminder

For other BT devices that can be activated, please carefully check the BT standards and compatibility before connecting.

▪FN+Shift+Key Combination Function in Windows System

Implementing ESC-F12 standard functions separately

Note: After connecting the device, you must press the FN+ corresponding system key to select the system, otherwise the keyboard function will be invalid.

▪Energy saving sleep mode

When there are no operating instructions on the keyboard within 10 minutes, the keyboard will automatically enter sleep mode. When needed, simply press any key and wait for about 3 seconds. The keyboard will be awakened and can function normally.

▪Charge method

When the voltage is below 3.2V, the “Charge” indicator light turns blue and flashes continuously. At this time, the keyboard needs to be charged. After connect the USB cable successful, the charging status “Charge” will be indicated in red. When the power is fully charged, then “Charge” indicator light will automatically turn off.

Information to User


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



[English] the power delivered by the charger must be between min [1] Watts required by the radio equipment, and max [5] Watts in order to achieve the maximum charging speed.

Operating Frequency Band: 2402MHz  
Maximum Radio-Frequency Power: 0.73dBm

Operating Frequency Band: 2440MHz  
Maximum Radio-Frequency Power: 0.34dBm

Operating Frequency Band: 2480MHz  
Maximum Radio-Frequency Power: -0.34dBm